

Railseal Installation Instructions for Startrack Panels

1. All cavities and rail surfaces must be clean and free of debris.
2. Field or Gauge rubber should be laid out and attached together with supplied end clips
3. Orient attached rubber profiles on top of the open cavity as shown in accompanying illustration RA-4115-176
4. Insert end of first rubber profile into end of panel cavity, If needed use peanut oil or dish soap on rubber surface to help slide rubber into place



5. Once started, a sledgehammer, backhoe tire or bucket with a block of wood can be used to help push the rubber in place, Repeat process until all parts installed.





FM 64466

POLYCORP LTD.

33 York Street, Elora, Ontario, Canada N0B 1S0 Toll Free: 1-800-265-2710 Tel: (519) 846-2075 Fax: (519) 846-2372
www.poly-corp.com



33 YORK STREET
ELORA, ONTARIO
CANADA NOB 1S0
800-265-2710

CLIENT

TITLE

CONCRETE PANEL INSTALLATION GUIDE

DWG. No.

RA-4115-176

DWN. M.JIN

DATE JAN28/21

REV.

SCALE NTS

THIS DRAWING HAS COPYRIGHT, WHICH IS OWNED BY POLYCORP. NEITHER THIS DRAWING ITSELF NOR ARTICLE NOR COMPONENT ILLUSTRATED THEREIN MAY BE REPRODUCED IN WHOLE OR IN PART, IN ANY FORM WHATSOEVER WITHOUT THE PRIOR WRITTEN AUTHORITY FROM POLYCORP. THIS DRAWING HAS BEEN DELIVERED ON THE UNDERSTANDING THAT IT IS NOT USED, IN ANY WAY, AGAINST THE INTERESTS OF POLYCORP AND WILL BE RETURNED UPON DEMAND.

ILLUSTRATION ONLY

FLEX HINGE FOR INSTALLATION

FLEX HINGE FOR INSTALLATION

115# A.R.E.A.

LEG NOTCHED HERE

LEG NOTCHED HERE

